


ADAMS COUNTY

SECTION SUMMARY

SECTION: 06
 TOWNSHIP: 17
 RANGE: 07

THIS MAP IS TO BE USED FOR REFERENCE ONLY. ADAMS COUNTY ASSUMES NO LEGAL RESPONSIBILITY FOR THE ACCURACY OF THE INFORMATION CONTAINED HEREIN.

LINCOLN
 CITY-VILLAGE, TOWN



06

ADAMS COUNTY COORDINATE SYSTEM NAD83 (2007)			
NUMBER	NORTHING	EASTING	DESCRIPTION
41706010000	219004.474	557381.415	HARRISON
41706012000	221644.459	557362.151	HARRISON
41707060020	218970.958	559822.374	HARRISON BROKEN TOP
41707060000	218934.957	562466.767	HARRISON
41707062000	221579.801	562438.805	HARRISON BROKEN TOP
41807310000	224422.659	562408.245	1-1/2" O.D. IRON PIPE
41807310020	224417.695	559764.465	HARRISON
41806360000	224412.751	557332.125	HARRISON

